



# ROCKETPEN READER

By SmartPens4U

## Quick Start Guide



### Content of box

- RocketPen Reader
- USB Type-C cable
- Earphones
- Quick Start Guide

Version: R1.13E

**SmartPens4U**

## **Thank you for buying RocketPen Reader from SmartPens4U.**

RocketPen Reader is designed to be a reading assistant, and our goal is to make you an independent reader. Whether you need to read exam questions, do your homework, or simply want to read your favorite novel, we hope reading becomes less challenging and more enjoyable for you. RocketPen Reader also supports literacy. The embedded dictionaries make understanding so much easier, faster, and more convenient.


RocketPen Reader is a stand-alone and self-contained product and works without being connected to any other device or network.

For technical specification and further information regarding additional features, supported languages, upgradability, battery, etc., please see:

[www.smartpens4u.com](http://www.smartpens4u.com)

Copyright© SmartPens4U Ltd.

# RocketPen Parts



## 1 – Power On/Off

Press 3 seconds to power device on or off. Press briefly to return from power-saving mode.

## 2 – Volume down button

## 3 – Volume up button

## 4 – Screen

The device's display touch screen

## 5 – Read button


## 6 – Back button

## 7 – Scan Trigger

Automatically activated when the pen is in contact with a paper. Scan light is turned on

## 8 – Type-C USB connector

Used for charging, upgrading and earphones



## 9 – Speaker

Used when text is read aloud. Muted when earphones are connected.


## Getting started:

Press and hold the power button for about 3 seconds. When the RocketPen Reader logo appears, release the button. After that, a logo animation should run, followed by the main menu:



(Note: If the display does not light up, charge the device for about 30 minutes).

## SmartRead application

1. Press the SmartRead application. A **Definition Dictionary** window appears. Your selection becomes the default dictionary. For changing the default, see SmartRead Settings . If there is more than one bilingual dictionary with the same source language, **Bilingual Dictionary** selection window appears.
  2. Once a dictionary was selected, "Ready to Scan with:..." screen appears:
- 4



3. Hold the pen on a printed text, press down gently, and start moving from left to right. Lift the pen from the paper to finish scanning.


Please scan the following line:

I discover the joy of reading



Swipe the screen left to see the end of the scanned line. For scanning from right to left, see **RocketPen Settings**.

4. Press the word “discover”, and action screen appears:



5. Action screen buttons:

**Definition** 

View the English definition of the word. See definition screen below.

**Syllabicate** 

View the syllabic division of the word:




*Note: not available in some dictionaries.*

**Translation** 

Translate the word.


*Note: not available for some languages.*

**Spell out** 

Hear the word spelled out.


*Note: Greyed-out buttons indicate that the function is not available for the specific word, phrase, language or dictionary.*

6. Press the required action: Definition, Syllabication, Translation or Spell out.

At any stage pressing the back button  will move to previous screen.

Note: Pressing the play button will read the scanned/selected word or sentence aloud.

## Definition screen




- 1 Switch to abridged view of dictionary entry
- 2 View alternative entries
- 3 SmartRead Settings, see below
- 4 Guides
- 5 Scroll bar: swipe the screen to scroll up and down or use the scroll bar
- 6 Definition/Translation
- 7 Part of speech of current headword
- 8 Headword

## Special features


There are several features which are dictionary related. In this section there is a description of the special features. Each feature is listed below its dictionary name.

**Oxford American Children's Dictionary**, and **New Oxford American Dictionary**:



View Synonyms of the word. Tap on the **THS** key, to access thesaurus entry. Tap on the **DEF** key to return to definition screen.

**Larousse French Dictionary**:




Click on **[conj. n]** to view how to conjugate the displayed verb.






The inflected forms of each verb are listed according to its modes and tenses.



Synonym

Antonym

Synonyms and Antonyms in Larousse French Dictionary are shown only in *full display view* .

## SmartRead Settings



### Always Read Aloud :

Use this option to change the settings of reading text aloud. The Pen's default: read aloud immediately.

### Definition Dictionary :

View a list of available monolingual dictionaries and change the default dictionary.

## **Translation Dictionary** :

Use this option to select different bilingual dictionary. (Only available if there is more than one bilingual dictionary)

## **QuickDefine Mode** :

Selecting *QuickDefine* mode skips the “Action Screen” and displays immediately the definition/translation according to the selection in *QuickDefine Dictionary*.

## **QuickDefine Dictionary** :

Use this option to select the dictionary for *QuickDefine Mode*.


## **Voice Settings** :

Use this option to modify the volume, reading speed, and to select a different voice.

## **Use Color** :

Unselect **Use Color** displays definition, thesaurus, or translation screens in black & white.

## **Lock Dictionary Access** :

Use this option to lock any access to the dictionaries on the Pen. When this option is activated, the lock icon  appears. Once *Lock*

*Dictionary* is activated, the menu item changes to *Unlock Dictionary Access*.

## **General Settings**

Includes the following general Pen settings:

### **Brightness**

Use this option to adjust the brightness of the display.

### **Screen Standby Time**

Use this option to change the default standby time.

### **Auto Shut-off Time**

Use this option to change the default shut-off time.

### **Left-Handed User**

Use this option to switch to left-handed user.

### **Scan Right-to-Left**

Use this option to switch to right-to-left scanning.

### **Interface Language**

View the list of available interface languages and change the default language.

### **Software Upgrade**


Use this option to install an upgrade package.

### **Factory Reset**

Use this option to reset all preferences.



# ExamRead application

1. Press the ExamRead application. “Ready to Scan in English in...” screen appears:



2. There are 2 scanning modes:

- a. Continuous scanning
- b. Single line scanning.

The default is Continuous scanning. Scan the lines one after another. By pressing the speaker button, the entire scanned text will be read aloud. Each word will be highlighted as it is spoken. To activate single line scanning mode, press the  icon. To reactivate continuous scanning mode, press the  icon.

# ExamRead Settings



## Scanning Language :

Use this option to modify the volume, reading speed, and to select a different voice.


## Voice Settings :

Use this option to modify the volume, reading speed, and to select a different voice.

## General Settings :

See p. 11.

## Information



Select *Info* to view the Pen version and copyright information.

RocketPen Reader is the trademark or registered trademark of SmartPens4U Ltd.