

Contour Disinfectant Wipes



Contour Disinfectant Wipes - Keep your Contour products clean!

With the Contour Disinfectant Wipes you can keep your Contour products clean of bacterias, fungus and virus. The disinfectant wipes are based on DESTIX® MA61, an 70% alcohol quick disinfection system that is suitable for all Contour products, but not suitable for alcohol unstable materials, such as acrylic glass. Contact time: 1 Minute!

General Information

Contour Disinfectant Wipes are ready-to-use disinfectant agents suitable for the disinfection of devices, where there's risk of infection and quick contact time is needed. Especially dedicated for small surfaces and all areas where quick disinfection is required. The disinfection solution and the wipes cannot be used with invasive medical equipment such as surgical instruments, hearing aids, earmolds.

Contour Disinfectant Wipes are effective against bacterias (incl. MRSA), fungi (Candida Albicans, Aspergillus niger) viruses (BVDV, Vaccina, Noro, Rota). Product has mycobactericidal and tuberculocidal efficiency (M.Terrae, M. Avium). Contact time: 1 minute.

Contour Disinfectant Wipes are fragrance free, and the disinfection liquid is free of aldehydes, formaldehyde and phenols.



contour 

www.contour-design.co.uk | info@contour-design.com

Contour Disinfectant Wipes

User Instructions

First clean the surface thoroughly with a Contour Disinfectant Wipe, allow the fluid to act for 1 minute before removing any residue with a clean dry wipe. Before application, please refer to the label and manufacturer's instructions.

Contour Disinfectant Wipes are not suitable for application on alcohol-unstable materials such as acrylic glass!

Warnings

Please place used tissues in the waste disposal. Do not use after expiry date. Keep out of the reach of children. Keep at temperature not exceeding 25 °C. If swallowed, seek medical advice immediately and show container or label. Avoid contact with skin.

Attention! Flammable. Contains alcohol.

Use product only for alcohol-resistant, non-porous surfaces.



Technical specifications

Ethanol (per 100 g disinfection liquid)	24 g
1-propanol (per 100 g disinfection liquid)	37 g
Durability	2 years from production date (unopened)
Alcohol vol.	70 %
Packaging	Cartons of 20 wipes